

snom

Quick Start Guide A190 Wireless DECT Headset



A Delivery content · Lieferumfang · Contenu de la boîte · En la caja · Contenuto della confezione






Connecting · Anschließen · B Connecter · Conectar · Collegare




Charging the battery · Akku laden ·

C Charger la batterie · Ricarica della batteria · Carga de la batería



v2019001



Registering the headset to M-series base stations

Set up an extension for the headset on the base station and put the base station into registration
mode for handsets. Please refer to the base station manual on how to do it. The headset's IPEI
number is on the box label.

 ${f Note}$: To be able to register a headset, you must set the AC code on the M900 **Extensions** page to 0000.

- Press the CALL key and the two VOLUME keys simultaneously for more than 5 seconds to put the headset into registration mode, as indicated by short blue flashes and the voice prompt announcing "registering."
- If the headset has been registered, the voice prompt announces "heaset subscribed," and the headset has been added to the extensions page (Fig. 1). It can now receive calls at the assigned extension number.

	<u>Idx</u>		<u>Handset</u> <u>State</u>	Handset Type FW Info	FWU Progress	VoIP Idx	Extension	<u>Display Name</u>
	1		Present@RPN00	450.5	Complete	1	80800	80800
	2		Present@RPN00		Complete	2	80802	80802
	3	0328D;	Present@RPN00	M90 450.5	Complete	3	<u>7777</u>	
	4	02E690		8930g 430.4	Off	4	<u>7789</u>	

Fig. 1

Pairing the headset with a handset

It is possible to pair the headset with a handset registered at the base station. The headset will get the same extension number as the handset, and you can assign its former extension number to another terminal.

- 1. On the extension page, click on the IPEI of the handset. The handset page opens.
- 2. From the drop-down box of Paired Terminal, select the terminal idx of the headset (Fig. 2).

IPEI:	0328D:		IPEI:	0328D1
Paired Terminal:	No Paired Terminal	•	Paired Terminal:	Terminal Idx 4 ▼
AC:	FFFF		AC:	FFFF
Alarm Line:	No Alarm Line Selected	•	Alarm Line:	No Alarm Line Selected ▼
Alarm Number:			Alarm Number:	

Fig. 2

Click Save. The headset is now registered with the same extension number as the handset and can also be used to call numbers dialed on the handset's keypad.

	<u>Idx</u>	<u>IPEI</u>	<u>Handset</u> <u>State</u>	Handset Type FW Info	FWU Progress	VoIP Idx	<u>Extension</u>
	1	0328D:	Present@RPN00	M70 450.5	Complete	1	80800
l	4	02E69(8930g 430.4	Off	1	80800
1	2	0328D:	Present@RPN00	M80 450.5	Complete	2	80802
	3	0328D2	Present@RPN00	M90 450.5	Complete	3	<u>7777</u>

Fig. 3

Using the headset

- Turning headset on: press AUX and both VOLUME keys for 5 seconds or place handset in charger.
- Turning headset off: press AUX and both VOLUME keys for 5 seconds.



Idle state

- Increase ringer volume: press VOLUME+ key
- Decrease ringer volume: press VOLUME- key
- Disable ringer audio (turn on silent mode): press VOLUME+ key for 2 seconds
- Enable ringer audio (turn off silent mode): press VOLUME- key for 2 seconds
- Enter voice prompt menu: press AUX key ...

Active state

Ringing calls can be accepted on the handset or on the headset and then picked up on the other device.

- Accept/terminate call: press CALL key (1x) O.
- Reject incoming call: press CALL key twice (2x) 🗑 👩
- Put call on hold/retrieve held call: press CALL key for 2 seconds ${\bigodot}$.

- Increase volume of call: press VOLUME+ key

 Decrease volume of call: press VOLUME- key

 Mute and unmute microphone: press MUTE key
- · Call waiting.
 - \circ Press CALL key to accept incoming and simultaneously terminate active call \odot .
 - Press CALL key **twice** to reject the incoming call \bigcirc \bigcirc .
 - \circ Press CALL key **for 2 seconds** to put the active call on hold and accept the second call \odot .
 - Switch active and held call: Press CALL key for 2 seconds O.

Swap call between headset and handset

Note: If the call is muted, it will be unmuted, if the call is on hold, it will be retrieved.

- Headset picking up from handset: Press the CALL key on the headset to continue the call on the headset .
- Handset picking up call from headset: Press the CALL key or the SPEAKERPHONE key on the handset to continue the call on the handset's receiver or speakerphone, respectively.

I FD indications

Color	LED indication	Status
Green	Short flash followed by long flash	Power up
Green	Long flash followed by short flash	Power down
Blue	Flashing fast	Registration, ongoing
Blue	Long flash	Registration completed
Red	Long flash	Registration failed
	None	Deregistered
Blue	Blinking slowly	Idle, connected
Red	Blinking slowly	Idle, out of range
Green	Flashing fast	Incoming call
Green	Flashing fast	2nd incoming call, call active, silent mode on
Green	Single short flash. Notification of call via audio in HS	2nd incoming call, call active, silent mode off
Green	Single short flash	In call
Red	Short flash	Low battery
Red	Steady on	Battery charging, low bat
Green	Long flash	Battery charging
Green	Steady on	Battery charging, full
Purple	Steady on	Menu

For further information, see wiki.snom.com/A190.

Snom Technology GmbH Wittestr. 30 G 13509 Berlin,Germany